	<b>IST-2002-002114 – ENACTIVE NETWORK OF EXCELLENCE</b> <b>RD33 Deliverable 1</b>
<b>Reference</b>	EI_D_RD33.1_INPG2_051025
<b>Title</b>	<b>State of the Art on Gesture Data Format in Motion Capture systems</b>
<b>Object</b>	RD33 Deliverable 1 : Chapter II
<b>Author</b>	Matthieu Evrard, Damien Couroussé, Annie Luciani
<b>Participants</b>	RD33 participants
<b>Dissemination</b>	RD33 participants
<b>Nb of Pages</b>	16 pages
<b>Date of the version</b>	2005, October 25th
<b>Confidentiality</b>	ENACTIVE Internal Restricted Use

## 1 Introduction

The use of motion capture for motion analysis and synthesis has begun in the late 1970's and is nowadays wide spread. Motion capture is the recording of human body movement (or other movement) for immediate or delayed analysis and playback. The information captured can be as general as the simple position of the body in space or as complex as the deformations of the face and muscle masses. Motion capture for computer character animation involves the mapping of human motion onto the motion of a computer character. The mapping can be direct, such as human arm motion controlling a character's arm motion, or indirect, such as human hand and finger patterns controlling a character's skin colour or emotional state. The most current systems that capture the movement are optical or magnetic systems.

In order to communicate between a motion capture system and an application that uses those data (for character animation or any kind of data processing), or between two applications, many file formats have been created. This document draws an overview of the most current exchange file formats in motion capture.

## 2 BVA and BVH file format

### 2.1. General description

BVH means Biovision Hierarchical Data. This format is one of the most currently used today. At the basis, Biovision, a motion capture company, has developed it. The BVA format, also developed by Biovision is the BVH primal form. This format is mainly used for the animation of humanoid structures and gives a standardised definition of them. The format is largely and successfully spread in animation community certainly because of its simple specifications. However, some lack can be notice especially the definition of the skeleton in its rest position (basis pose), which seems to be incomplete and the lack of indication dedicated to the representation of the segments. BVA and BVH files are ASCII files.

In a BVA file, sample coming from each segment of the skeleton are stock in a more or less raw manner, without taking into account the structure of the animated form. For this reason Biovision has then developed the BVH format.

A BVH file is divided into two sections. The head section describes the structure (hierarchy, parent links) and the basis pose of the skeleton. The following section contains the data concerning the movement. The space, in this type of representation, is defined as a direct orthonormed system where the Y-axis is the vertical one. So, the segments of the skeleton are generally aligned following this axis in its rest position.

### 2.2. Example of a BVA file

```
Segment:  Hips
Frames:    2
Frame Time: 0.033333
XTRAN  YTRAN  ZTRAN  XROT  YROT  ZROT  XSCALE  YSCALE  ZSCALE
INCHES  INCHES  INCHES  DEGREES  DEGREES  DEGREES  INCHES  INCHES  INCHES
  8.03   35.01   88.36   14.78  -164.35  -3.41    5.21    5.21    5.21
  7.81   35.10   86.47   12.94  -166.97  -3.78    5.21    5.21    5.21
Segment:  Chest
Frames:    2
Frame Time: 0.033333
XTRAN  YTRAN  ZTRAN  XROT  YROT  ZROT  XSCALE  YSCALE  ZSCALE
INCHES  INCHES  INCHES  DEGREES  DEGREES  DEGREES  INCHES  INCHES  INCHES
```

```

8.33    40.04    89.69   -27.24   175.94 -2.88    18.65    18.65    18.65
8.15    40.16    87.63   -31.12   175.58 -4.08    18.65    18.65    18.65
Segment: Neck
Frames: 2
Frame Time: 0.033333
XTRAN  YTRAN  ZTRAN  XROT  YROT  ZROT  XSCALE YSCALE ZSCALE
INCHES INCHES INCHES DEGREES DEGREES DEGREES INCHES INCHES INCHES
9.16    56.60    81.15   -69.21   159.37 -27.46    5.45    5.45    5.45
9.28    56.09    78.00   -72.40   153.61 -33.72    5.45    5.45    5.45
Segment: Head
Frames: 2
Frame Time: 0.033333
XTRAN  YTRAN  ZTRAN  XROT  YROT  ZROT  XSCALE YSCALE ZSCALE
INCHES INCHES INCHES DEGREES DEGREES DEGREES INCHES INCHES INCHES
10.05   58.32    76.05   -29.04  -178.51 -8.97     3.87    3.87    3.87
10.20   57.46    72.80   -32.77  -179.46 -9.60     3.87    3.87    3.87

```

### 2.3. Descriptive section of the hierarchical structure in BVH file

The form to animate is defined in a recursive manner: each segment is defined by its own parameters and by its parentage with an other segment. The head section start with the key word HIERARCHY.

The structure is described in this section. The first element described is the root element indicated by the ROOT keyword. The structure is defined from this first element. The links between the different segments are modelled by a father relation or by a son relation. New hierarchies can be added to the file by adding new ROOT keywords.

Information associated with each nodes of the hierarchy is:

- The offset (OFFSET keyword) gives the position relatively to origin for the root segment and to the parent position for the other segments.
- A number that indicate the number of channels and the name of each channel follows the CHANNEL keyword. A channel carries a one-dimensional signal (position or orientation of the segment relatively to its parent). The root segment generally has six channels (three for the position and three for the rotations) while the other segments generally have 3 channels (the 3 rotations because the joins are fixed in relative translation). Nevertheless it is possible to add channels depending on the user wishes.
- JOINT has the same function than ROOT but is used for the declaration of a son segment. Every son segment of a given father has to be declared in the father structure.
- The “End Site” token closes a hierarchy and means that a segment is a leaf of it. The OFFSET of this ending segment is finally given.

### 2.4. The data section

The section that contains the movement data starts by the key word MOTION. The next two lines successively give the number of frame and the sampling period. The data of each frame are then disposed one after one on the same line. We change of line for each new frame.

Here is an example of a BVH file

### 2.5. Example of a BVH file

HIERARCHY  
ROOT Hips

Start of the head

```
{
  OFFSET 0.00 0.00 0.00
  CHANNELS 6 Xposition Yposition Zposition Zrotation Xrotation Yrotation
  JOINT Chest
  {
    OFFSET 0.00 5.21 0.00
    CHANNELS 3 Zrotation Xrotation Yrotation
    JOINT Neck
    {
      OFFSET 0.00 18.65 0.00
      CHANNELS 3 Zrotation Xrotation Yrotation
      JOINT Head
      {
        OFFSET 0.00 5.45 0.00
        CHANNELS 3 Zrotation Xrotation Yrotation
        End Site
        {
          OFFSET 0.00 3.87 0.00
        }
      }
    }
  }
  JOINT LeftCollar
  {
    OFFSET 1.12 16.23 1.87
    CHANNELS 3 Zrotation Xrotation Yrotation
    JOINT LeftUpArm
    {
      OFFSET 5.54 0.00 0.00
      CHANNELS 3 Zrotation Xrotation Yrotation
      JOINT LeftLowArm
      {
        OFFSET 0.00 -11.96 0.00
        CHANNELS 3 Zrotation Xrotation Yrotation
        JOINT LeftHand
        {
          OFFSET 0.00 -9.93 0.00
          CHANNELS 3 Zrotation Xrotation Yrotation
          End Site
          {
            OFFSET 0.00 -7.00 0.00
          }
        }
      }
    }
  }
}
```


```
JOINT RightCollar
{
  <structure identical to the left collar>
}
JOINT LeftUpLeg
{
  OFFSET 3.91 0.00 0.00
  CHANNELS 3 Zrotation Xrotation Yrotation
  JOINT LeftLowLeg
  {
    OFFSET 0.00 -18.34 0.00
    CHANNELS 3 Zrotation Xrotation Yrotation
    JOINT LeftFoot
    {
      OFFSET 0.00 -17.37 0.00
      CHANNELS 3 Zrotation Xrotation Yrotation
      End Site
      {
        OFFSET 0.00 -3.46 0.00
      }
    }
  }
}
JOINT RightUpLeg
{
  <structure identical to the LeftUpLeg>
}
```

Start of the data section

```
MOTION
Frames: 2
Frame Time: 0.033333
8.03 35.01 88.36 -3.41 14.78 -164.35 13.09 40.30 -24.60 7.88 43.80 0.00 -3.61 -41.45 5.82 10.08 0.00
7.81 35.10 86.47 -3.78 12.94 -166.97 12.64 42.57 -22.34 7.67 43.61 0.00 -4.23 -41.41 4.89 19.10 0.00
```

channels of the root segment      channels of the first son segment

The structure defined in this example (which is the basis structure for the BVH format) can be schematised in the following way:



Many problems are inherent to the BVH format. The most remarkable is that orientation and position of each segment are not absolute. It can lead to a huge cost in terms of processing to obtain the position and the orientation for a segment at the leaf of the hierarchy.

Another problem is the lack of calibration for data such as the scale with which the offsets are measured... It becomes very hard to treat several files for which the capture process was not the same (done in the same conditions).

### 3 ASK/SDL file format

The format is a variant of the BVH file format developed by Biovision. The ASK file (Alias Skeleton) only contains information concerning the skeleton and, as a result, does not contain any information about the channels or the movement. The offset coordinates are absolute unlike the BVH in which they are relative.

The SDL file associated to the ASK file contains the data of the movement but it can contain many other information concerning the scene than the very samples of the movement.

## 4 MNM file format

This file format allows renaming the segments of a BVH file: a name defined by the user is associated to the predefined label in the BVH file.

## 5 AOA file format

### 5.1. General description

Adaptative Optics is a company dedicated to the creation of hardware support for the motion capture. This ASCII file format simply describes the captors and their position at each sampling period. It is divided into two sections.

The first section (the head section) contains two lines:

- A commentary line without any peculiar starting character.
- A line with three tokens : frames = <number of frames> [space] nLimmarkers = <number of marker on each sample> [space] hz = <sampling frequency>

Inside the data section, the XYZ positions are given. One line is equal to one marker and once a sample is over a new one starts. No name is associated with the values. Therefore the structure is implicit.

### 5.2. Example of an AOA file

AOA file written by LambSoft Pro Motion

frames = 2 nummarkers = 10 hz = 30

131.1524	163.0935	71.6937
124.6823	71.3264	76.5239
121.2981	102.4109	75.0063
149.2998	181.1166	132.8877
134.7889	192.6069	116.5414
122.5840	190.7085	89.0098
149.5519	239.0187	104.2023
131.1980	121.0528	101.0101
160.2013	95.1255	134.9703
137.7529	47.9096	96.5317
131.2017	163.1528	71.7291
124.6200	71.3926	76.5561
121.2042	102.5331	75.0017
149.3542	181.1748	132.9477
134.8884	192.6407	116.6287
122.3916	190.7327	88.9545
149.5145	239.0789	104.2528
131.3174	121.1239	101.0545
160.1843	95.1614	135.0377
137.7782	47.9176	96.5733

## 6 The ASF/AMC file format

### 6.1. General description

This format was developed by Acclaim, a video game company. Once entered in the public domain it has been used by Oxford Metrics (Vicon Motion Capture Systems).

The Acclaim format is composed of two different files, one for the skeleton and the other one for the movement. The separation between these two types has been done because the same

skeleton is often used for numerous distinct movements. The file containing the skeleton description in the ASF file (Acclaim Skeleton File) and the file containing the movement data is the AMC file (Acclaim Motion Capture data).

## 6.2. The ASF file

The starting point of the motion capture is the basis position of the skeleton. Each file has only one root segment, therefore only one structure. Each segment carries information useful for its geometric representation as well as information concerning the dynamic of the character. The same information than the other format on this type is present (id, name, length, rotation axes, degree of freedom...) but information about the interval of the possible movement for each rotation (from the basis position) is added.

## 6.3. Example of an ASF file

```
#
# Comment line
##
#
:version 1.10
:name BioSkeleton
:units
    mass 1.0
    length 1.0
    angle deg
:documentation
    Example of an Acclaim skeleton
    To be used with "Walk.amc"
:root
    axis XYZ
    order TX TY TZ RZ RY RX
    position 0.0 0.0 0.0
    orientation 0.0 0.0 0.0
:bonedata
begin
    id 1
    name hips
    direction 0.000000 1.000000 0.000000
    length 0.000000
    axis 0.00000 0.00000 0.00000 XYZ
    dof rx ry rz
    limits (-180.0 180.0)
        (-180.0 180.0)
        (-180.0 180.0)
end
begin
    id 2
    name hips1
    direction 0.000000 1.000000 0.000000
    length 4.310000
    axis 0.000 0.000 0.000 XYZ
end

identical declaration for join 3 to join 24

:hierarchy
begin
    root hips
    hips hips1 hips2 hips3
    hips1 chest
    chest chest1 chest2 chest3
    chest1 neck
    neck head
    chest2 leftcollar
    leftcollar leftuparm
    leftuparm leftlowarm
    leftlowarm lefthand
    chest3 rightcollar
    rightcollar rightuparm
```

```

rightuparm rightlowarm
rightlowarm righthand
hips2 leftupleg
leftupleg leftlowleg
leftlowleg leftfoot
hips3 rightupleg
rightupleg rightlowleg
rightlowleg rightfoot
end

```

#### 6.4. The AMC file format

This file contains the data concerning the movement of the skeleton. The samples are given one after one. A sample is presented on several lines (one for a segment and all of its degree of freedom).

#### 6.5. Example of an AMC file associated with the ASF file above

```

# Space for comments
##
#
:FULLY-SPECIFIED
:DEGREES
1
root -1.244205 36.710186 -1.148101 0.958161 4.190043 -18.282991
hips 0.000000 0.000000 0.000000
chest 15.511776 -2.804996 -0.725314
neck 48.559605 0.000000 0.014236
head -38.332661 1.462782 -1.753684
leftcollar 0.000000 15.958783 0.921166
leftuparm -10.319685 -15.040003 63.091194
leftlowarm -27.769176 -15.856658 8.187016
lefthand 2.601753 -0.217064 -5.543770
rightcollar 0.000000 -8.470076 2.895008
rightuparm 6.496142 9.551583 -57.854118
rightlowarm -26.983490 11.338276 -5.716377
righthand -6.387745 -1.258509 5.876069
leftupleg 23.412262 -5.325913 12.099395
leftlowleg -6.933442 -6.276054 -1.363996
leftfoot -1.877641 4.455667 -6.275022
rightupleg 20.698696 3.189690 -8.377244
rightlowleg 3.445840 -6.717122 2.046032
rightfoot -8.162314 0.687809 9.000264
2
root -0.227361 37.620358 1.672587 0.204373 -4.264866 -12.155879
hips 0.000000 0.000000 0.000000
chest 14.747641 2.858763 -1.345236
neck 44.651531 0.000000 -0.099206
head -38.546989 0.678145 -4.633668
leftcollar 0.000000 7.233337 -5.791124
leftuparm 9.928153 -50.015823 25.218475
leftlowarm -40.443512 -0.566324 0.482702
lefthand 6.011584 -0.216811 4.576208
rightcollar 0.000000 -1.936009 5.471129
rightuparm 3.926107 32.418419 -26.396805
rightlowarm -43.958717 3.548671 -3.415734
righthand -4.901258 -0.112565 0.681468
leftupleg 11.932759 0.406248 -1.921313
leftlowleg 13.698170 5.503362 2.643481
leftfoot -16.237123 2.755839 -7.182952
rightupleg 13.767217 0.331739 -1.353482
rightlowleg 22.576195 -7.388037 -3.537788
rightfoot -19.946142 2.525145 8.668705

```



## 7 The BRD file format

### 7.1. General Description

The format is uniquely used by the motion capture system Ascension Technology “Flock of Birds” developed by LambSoft. It allowed stocking the data coming from a magnetic system. The first number is the sample number; the first sample in the file is sample 0. The second number is the marker number. The first marker is marker 0. The next token is "P", this indicates that the next three values on the line are position values for the marker.

After the position values the token "Q" appears. This indicates that the next 4 values are quaternions. The last two values on each line are optional. These are the time stamp values for each marker. These numbers are identical to the values returned by the Unix system call `gettimeofday()` (The system call `ftime()` under Windows does a similar thing except it returns milliseconds). The first number is in seconds; the second number is in microseconds. It is possible for the time stamp values of one marker to be different from the time stamp values for a second marker in the same sample.

### 7.2. Example of a BRD file

```
0 0 P 55.9477 32.7718 -5.2410 Q 0.7569 0.3548 -0.4984 0.2299 0
000000
0 1 P 52.5374 26.9382 9.3167 Q -0.6740 -0.4260 -0.5366 0.2762 0
000000
1 14 P 43.0703 48.2499 -39.1160 Q 0.8875 -0.4361 0.1333 0.0660 0 16666
1 15 P 49.5336 30.1453 4.2165 Q -0.7198 -0.3039 -0.5944 0.1904 0 16666
2 0 P 57.7803 34.8796 -4.7169 Q 0.7569 0.3548 -0.4984 0.2299 0 33332
2 1 P 53.8193 29.2250 9.4211 Q -0.6740 -0.4260 -0.5366 0.2762 0 33332
```

## 8 The HTR and GTR file formats

### 8.1. General description

The HTR format (Hierarchical Translation Rotation) has been developed as a native format for the skeleton of the Motion Analysis software. It has been created as an alternative to the BVH format to make up for its main drawbacks. A HTR variant exist which is called the GTR format (Global Translation Rotation) and is the same format less the structural information. This format has known few uses.

The HTR format is divided into 4 sections: head, hierarchy and name of the segments, basis position and movement data.

The head section marked by the [HEADER] token contains many data lines including information carried by the BVH format plus:

- The number of segment
- The disposition of the eulerian angles
- The calibration unities
- The rotation unities
- The axes following which the gravity is exerted
- The axis flowing which the segments of the skeleton are aligned
- The global scale factor

One of the interests of this format is that the hierarchy [SegmentNames&hierarchy] is given separately of the characteristic of each segment [BasePosition] what simplifies the reading.

Moreover, the movement data are not indicated by a key word but by the name of the concerned segment.

## 8.2. Example of a HTR file

```
[Header]
FileType      htr          # Header keywords are followed by a single value
DataType      HTRS         # single word string
# Hierarchical translations followed by rotations and Scale
FileVersion   1           # integer
NumSegments   18          # integer
NumFrames     2           # integer
DataFrameRate 30          # integer
EulerRotationOrder ZYX    # one word string
CalibrationUnits mm       # one word string
RotationUnits Degrees     # one word string
GlobalAxisofGravity Y     # character, X or Y or Z
BoneLengthAxis Y
[SegmentNames&Hierarchy]
#CHILD PARENT
LOWERTORSO    GLOBAL
UPPERTORSO    LOWERTORSO
NECK          UPPERTORSO
HEAD          NECK
RSHOULDER     UPPERTORSO
RUPPERARM     RSHOULDER
RLOWARM RUPPERARM
RHAND         RLOWARM
LSHOULDER     UPPERTORSO
LUPPERARM     LSHOULDER
LLOWARM LUPPERARM
LHAND         LLOWARM
RTHIGH        LOWERTORSO
RLOWLEG RTHIGH
RFOOT         RLOWLEG
LTHIGH        LOWERTORSO
LLOWLEG LTHIGH
LFOOT         LLOWLEG
[BasePosition]
#SegmentName Tx, Ty, Tz, Rx, Ry, Rz, BoneLength
LOWERTORSO    0.00      0.00      0.00      0.00      0.00      0.00      0.00      200.00
UPPERTORSO    0.00      200.00    0.00      -1.38     0.00      0.35     286.95
NECK          0.00      286.95    0.00      2.90     -0.08     3.20     101.66
HEAD          0.00      101.66    0.00     -1.53    -0.09    -3.55     174.00
RSHOULDER     -10.21    252.02    -0.84     1.85    -1.36     98.76    137.50
RUPPERARM     0.00      137.50    0.00      3.22     0.48     13.42    279.07
RLOWARM 0.00    279.07      0.00     -2.42    -1.40    -15.48    222.64
RHAND         0.00      222.64    0.00     -2.59    -0.32    -6.98     90.00
LSHOULDER     9.79      251.90    -0.84     -5.30     1.36    -98.63    132.79
LUPPERARM     0.00      132.79    0.00     13.46     1.21    -13.67    295.17
LLOWARM 0.00    295.17      0.00     -6.60     2.65     18.04    222.81
LHAND         0.00      222.81    0.00     -1.49     0.10     3.78     90.00
RTHIGH        -96.49    -31.41     26.89     -6.15     0.00    176.17    379.17
RLOWLEG 0.00    379.17      0.00      4.86     -0.14     1.34    394.60
RFOOT         0.00      394.60    0.00     71.40    -0.06     2.48    160.00
LTHIGH        107.90    -45.36     2.84     -4.81     0.00   -178.69    362.85
LLOWLEG 0.00    362.85      0.00      5.06     -0.03     0.30    398.36
LFOOT         0.00      398.36    0.00     69.87    -0.01    -1.61    160.00
[LOWERTORSO]
1      263.72    816.20  -2874.77    18.03    -7.70   -10.34     1.00
2      264.42    812.41  -2740.34    19.81   -13.46   -11.93     1.00
[UPPERTORSO]
1      0.00      0.00      0.00      8.33   -17.38     8.59     1.00
2      0.00      0.00      0.00      8.71    -6.14     8.64     1.00

Same declaration for marker 3 to 18

[EndOfFile]
```

## 9 The TRC file format

### 9.1. General description

The TRC file format is another file format from Motion Analysis. It contains not only the raw data from the full body motion capture system they developed but also the output data coming from their face tracker. The output data of the face tracker are 2D data. So to allow merging 2D and 3D data the Z-coordinate value is set to 0 in the 2D case. The positions are given in absolute coordinate. Each marker has a name and is only referenced by its in the format.

### 9.2. Example of a TCR file

```
PathFileType      3          (X/Y/Z) Example.trc
DataRate CameraRate NumFrames NumMarkers Units
30 30 2 31 mm
Frame# Time      bridge clowlip cuplip lbrow1 lbrow2 lbrow3 lhead llaugh llcheek lllowjaw
          lllowlip lmouth lsocket lucheek lupjaw luplip nose rbrow1 rbrow2 rbrow3 rhead
          rlaugh rlccheek rllowjaw rllowlip rmouth rsocket rucheek rupjaw ruplip rtophead
X1 Y1 Z1 X2 Y2 Z2 X3 Y3 Z3 X4 Y4 Z4 X5 Y5 Z5 X6 Y6 Z6 X7 Y7 Z7 X8 Y8 Z8 X9 Y9 Z9 X10
Y10 Z10 X11 Y11 Z11 X12 Y12 Z12 X13 Y13 Z13 X14 Y14 Z14 X15 Y15 Z15 X16 Y16 Z16 X17 Y17
Z17 X18 Y18 Z18 X19 Y19 Z19 X20 Y20 Z20 X21 Y21 Z21 X22 Y22 Z22 X23 Y23 Z23 X24 Y24 Z24
X25 Y25 Z25 X26 Y26 Z26 X27 Y27 Z27 X28 Y28 Z28 X29 Y29 Z29 X30 Y30 Z30 X31 Y31 Z31

1          0.033333 131.1524 163.0935 71.6937 124.6823 71.3264 76.5239 121.2981 102.4109
75.0063 149.2998 181.1166 132.8877 134.7889 192.6069 116.5414 122.5840 190.7085 89.0098
149.5519 239.0187 104.2023 131.1980 121.0528 101.0101 160.2013 95.1255 134.9703 137.7529
47.9096 96.5317 128.6441 74.4367 94.9948 137.1264 85.1827 106.0074 139.9505 145.9818
111.2604 150.6080 130.9824 134.3215 204.5324 77.3407 144.1150 125.4540 99.9015 93.0702
111.0689 124.5950 72.5558 158.4736 184.0863 17.1546 139.9273 193.7812 32.1008 125.5029
190.9568 57.3250 148.4869 240.4077 55.7514 130.7053 120.1502 48.0696 161.9311 89.6753
21.3688 140.7662 47.0322 54.0298 129.6595 71.2903 57.0318 137.0737 83.6635 44.6577
143.2580 143.2805 37.2008 157.8477 128.4386 17.5263 200.7793 81.9230 9.8090 125.3299
99.0036 56.1530 131.1743 209.7377 71.5724
2          0.066667 131.2017 163.1528 71.7291 124.6200 71.3926 76.5561 121.2042 102.5331
75.0017 149.3542 181.1748 132.9477 134.8884 192.6407 116.6287 122.3916 190.7327 88.9545
149.5145 239.0789 104.2528 131.3174 121.1239 101.0545 160.1843 95.1614 135.0377 137.7782
47.9176 96.5733 128.6558 74.4725 95.0168 136.8899 85.2499 105.9204 139.9980 146.0101
111.2198 150.5929 131.0192 134.3598 204.5233 77.3376 144.1167 125.4860 100.0971 93.2541
111.0917 124.6370 72.5714 158.4663 184.0818 17.2422 139.9324 193.8225 32.1557 125.5762
190.9936 57.3842 148.5566 240.4861 55.8336 130.7453 120.2003 48.1136 161.9240 89.7217
21.3911 140.4146 47.1341 53.9443 129.6737 71.3267 57.0585 137.0995 83.7806 44.6918
143.3501 143.4694 37.4252 157.7448 128.5400 17.5307 200.9130 81.9462 9.9033 125.3576
99.0523 56.1991 131.2355 209.8056 71.6000
```

## 10 The CSM file format

### 10.1. General description

The CSM format is an optical tracking format that is used by Character Studio (an animation and skinning plug-in for 3D Studio MAX) for importing marker data. For CSM files to be compatible with Character Studio, they must use names that match the Character Studio setup and they must have an appropriate number of markers in specific locations on the actor. The CSM format itself is capable of holding any kind of marker data, but by being in the CSM (Character Studio Marker) format it is assumed that it also adheres to the name and marker configuration required by Character Studio. The motion data are given in the implicit order of the declaration of the joints.

### 9.2. Example of a CSM file

```
$comments
This is a Character Studio 2.0 CSM File
```

```

$firstframe 1

$lastframe 3

$spinelinks 3

$rate 60

$order
C7 CLAV LANK LBHD LBWT LELB LFHD LFIN LFWT LKNE LSHO LTOE LUPA LWRA LWRB RANK RBHD RBWT RELB
RFHD RFIN RFWT RKNE RSHO RTHI RTOE RWRA RWRB STRN T10

$points
1      980.6   -2365.8 1541.3 1030.6   -2239.9 1492.1 967.3   -2427.5 181.8   936.2   -2330.1
      1672.9  939.4   -2359.1 1109.3  782.9   -2263.3 1175.7  959.0   -2196.9 1753.8  762.3   -
2135.1  862.6  949.3   -2187.2 1082.1  934.2   -2343.2 583.1   870.4   -2246.7 1525.4 1031.7   -
2339.7  83.1   814.6   -2218.7 1318.8  799.4   -2132.3 993.7   729.2   -2230.2 966.5   1110.1   -
2060.1  197.3  1066.8   -2351.6 1670.5 1114.0   -2391.4 1116.4 1290.5   -2574.6 1396.5 1105.7   -
2231.2  1740.1 1217.5   -2369.8 1149.5 1159.8   -2233.6 1093.8 1138.8   -2119.2 605.9   1136.6   -
2342.8  1564.9 1081.3   -2126.7 775.0   1065.2   -1944.5 112.2   1276.8   -2398.1 1271.2 1294.0   -
2490.1  1183.6 1044.2   -2199.9 1395.9 988.1   -2404.3 1417.4
2      979.8   -2358.9 1540.1 1029.4   -2232.4 1489.5 966.5   -2426.7 181.8   936.2   -2322.0
      1671.1  940.7   -2351.6 1107.3  783.9   -2249.8 1173.7  959.4   -2189.0 1752.6  767.9   -
2113.2  863.4  948.9   -2177.9 1080.7  934.4   -2338.9 583.3   871.7   -2242.9 1523.4 1031.7   -
2339.5  82.9   814.6   -2207.6 1317.8  803.3   -2113.8 994.5   732.4   -2209.8 964.1   1108.3   -
2039.1  197.5  1067.2   -2343.2 1669.3 1115.0   -2382.1 1115.0 1292.6   -2563.1 1400.3 1106.5   -
2223.7  1738.5 1212.0   -2367.2 1155.5 1162.2   -2222.1 1093.8 1140.2   -2119.4 601.9   1135.4   -
2334.3  1563.9 1079.9   -2109.1 774.4   1064.5   -1921.3 116.0   1278.4   -2396.2 1273.8 1284.5   -
2483.4  1186.2 1043.6   -2192.5 1394.0 987.5   -2397.7 1415.2

```

## 11 The National Institute of Health C3D file format

### 11.1. General description

Many of the motion capture companies are often linked to the biomechanics research. The systems are then used to assess the performances of an athlete or the needs of a physically handicapped person. The needs of researchers, often supplied by more than one society, lead to the definition of a common format, the C3D format. This format has been built following this philosophy, so it has tried to carry the most complete amount of information useful for the biomechanics research. The features below was considered as necessities:

- The possibility to stock analogical data (i.e. directly coming from the measure instrument) and three-dimensional data (obtained by the information processing).
- The possibility to stock information on the material, which have been used (position marker, force captors), on the recording process (sampling rate, date, type of examination...), on the subject itself (name, age, physical parameters...).
- The possibility to add new data to the ones already recorded.
- The file was a binary file unlike most of motion capture file format, which often are ASCII files.

Therefore, the C3D format is a standard, which can be put aside because of its ability to stock a large amount of data types. This format is used by Adtech, ANZ, BTIS, C-Motion, Charnwood, Innovision Systems, Kaydera Inc., Lambsoft, Motion Analysis Corporation, Motion Lab Systems, National Institutes of Health, Oxford Metrics, Peak Performance Technologies, Qualisys, RUN technologies, Vicon Motion Systems...

The C3D format contains to principal data type: position data (3D coordinates after processing) and what the C3D calls analogical data, which actually are the raw data. The 3D coordinates are stocked into successive samples of XYZ coordinates with information on accuracy and specification of the captors. Each sample of a numerical data coming from a

processing is linked to its source. So it becomes very easy to correct some numerical values or to access to the source data.

### *11.2. The header section*

The header of the file is typically a 256 words of 2 bytes structure:

Byte	Typical value	Description
1	0x5002 hex	Byte 1 : number of the first recording parameter (typically 02) Byte 2 : keyword (50 hex) indicating a
2	-	Number of points recorded
3	-	Number of analogical chanel by sample.
4	1	Number of the first sample
5	-	Number of the last sample
7-8	-	Scale factor (a negative factor means no scale)
9	-	DATA_STAKT : number indicating the start of the recording
10	-	Number of analogical sample in a sampling interval for the 3D data
11-12	-	Sampling rate for the 3D data

### *11.3. Parameter record*

The location of the first parameter record is given inside the header. The first 4 bytes of the parameter record contain the following header:

Byte	Typical value	Description
1	0x00 hex	parameter file indicator
2	0x00 hex	parameter file indicator
3	-	Number of parameter record that follow
4	85	83 + processor type type 1 - PC DOS type 2 = DEC (VAX, PDP-11) type 3 = MIPS (SGI, SUN)

The parameters are stock just after the header. They are organized into groups, each parameter belong to only on group. Each parameter and each group are defined by the same header format.

18 events can also be defined in a C3D file. They are instances used to define, for instance, the beginning or the end of a ground contact. The event units can content one to four labels, its execution moment relatively to the first sample, etc.

### *11.4. Recording of the data*

Then follow the parameters themselves. They can appear inside the file whatever the order can be. The order just has to follow the one defined by the headers.

The 3D data and the analogical data are written in the file as sequential fields:

Analogical data for the field number 1
Analogical data for the field number 2
3D data for the field number 2
Analogical data for the field number N
3D data for the field number N

### 11.5. 3D position data format

- Integer data:

The data are stored in 4 words, the X, Y and Z coordinates in the first 3 words. The fourth word contains information on the captor used for the measure and on the measure error after interpolation.

- Floating point data:

The data are also stored in 4 words, which are dedicated to the same things than in the integer case.

## 12 A standardisation of the humanoid structures: the MPEG-4 standard

The amount of proposed format, the needs of the users, the future development associated with the object-oriented way of coding in the multimedia community lead to the definition of a new file standard for the following application:

- Digital television
- Interactive graphics applications (synthetic content)
- Interactive multimedia (World Wide Web, distribution of and access to content)

Inside this standard, a common structure for modelling the human skeleton and animating it has been proposed.

The data transmission is made in two steps:

- Humanoid structure initialisation before its animation. The data transmitted here will remain unchanged during the running of the application: structure of the skeleton, information on the surface texture, etc. The skeleton structure is defined as follow:
  - 6 degrees of freedom for the whole animated form
  - 62 degrees of freedom for the own movement of each skeleton.
  - The hand structure is defined apart and has 25 degrees of freedom. This is an optional structure, which can be omitted for low data rate transmission.

The skeleton is defined with 59 segments or 29 segments without the hands.

- Update of the structure during the animation.

Many optimisations are possible through this format like the reduction of the number of byte used for each degree of freedom, the maximum being 4 bytes. Priority rules for data transmission have been also proposed. In this case the most important parts of the body should be actualized in priority. So, the priority order proposed is (from the most important to the less important):

- The global position and orientation of the skeleton

- The orientation angle having a great visual importance for the animation: shoulders, knee, elbow, leg, and some peculiar joins of the hand.
- The other values

### 13 Conclusion

Most of the file formats presented are largely used in today motion capture based applications. For instance, the most popular animation tools (3DS Max, Maya, Lightwave...) all support the importation of BVH files. The case is the same for C3D file, which is largely a standard in biomechanics research. Some files are more oriented for one system like the CSM file of Character Studio.

The main limitations for real time uses is that most of the available formats presented her are ASCII formats (except C3D file format). It can be a limitation for applications that need to run in real-time and that need to consume data, which is stocked in a hard drive. If we look at the case of multimedia for instance, sound or movie are coded into binary files what allows the reader software a fast access to the data.

In addition, most of those file formats are dependant of the application:

- The C3D is really biomechanical data centred. The presence of analogical data (raw data in C3D language), the link with the 3D data, information about captors, 3D orientation (what do we do with 2D or 1D data?) , are features that can't really be considered as generic. Nevertheless this is the only binary format, it is widely spread in biomechanical research community, and it is also supplied by the most known motion capture systems. Kaydera's FILMBOX gesture editor also allow import/export of C3D files what link C3D file with the Computer Graphics community in a certain sens. Moreover it is constructed to be flexible (ability to add new data structure) and very well documented (the web site is really well shaped and very accurate).
- BVH, HTR, ASF/AMC, MNM files are very skeleton dependant what make their use very oriented to character animation.
- AOA is quite less oriented but only considered 3D coordinate.
- TCR could allow taking into account data of different dimensionalities but is sadly an ASCII file.
- BRD is oriented by the magnetic technology of Ascencion Technology Corporation.
- CSM is dedicated to the Character Studio software

### 14 Source and bibliography

- Optical systems :
  - Adaptive Optics Associated : <http://www.aoainc.com>
  - Mikromak GmbH : <http://www.mikromak.com>
  - Motion Analysis Corporation : <http://www.motionanalysis.com>
  - Vicon Motion Systems : <http://www.vicon.com>
- Magnetic systems :
  - Ascencion Technology Corporation : <http://www.ascension-tech.com>
  - Euclid Research : <http://www.euclidres.com>
  - Data Glove iReality : <http://www.genreality.com>
  - Polhemus : <http://www.polhemus.com>

- Hybrid systems
  - MetaMotion : <http://www.metamotion.com>
  - Digits'n Art : <http://www.dnasoft.com>
  - PuppetWorks : <http://www.puppetworks.com>
- File Format
  - Biovision Motion Capture Services : <http://www.biovision.com>
  - Many file formats : <http://www.cs.wisc.edu/graphics/Courses/cs-838-1999/Jeff/>
  - C3D file format (very well described) : <http://www.c3d.org>

Meredith, Maddock. *Motion capture file formats explained*. Internal report. Department of Computer Science, University of Sheffield, 2000.

Susan Van Baerle. *Motion Editing : Principles and Practice*. 2000 Game Development Conference Proceedings. March 20-24, 2000. San Jose, CA.